

# STANDARD GRAVITY LATCH

**NW38204**

## INSTRUCTIONS

**NOTE:** Hinges should be installed on opposite side of your gate.

1. Fix gate in desired location.
2. Place latch at desired location near the top of your post and mark the 4 hole locations. (Fig. 1 & 2)
3. Drill 4 pilot holes 1" deep with 7/32" drill.
4. Mount the latch with 4 included #10x 1-1/4" pan head screws.
5. Place the striker piece at desired location on your gate even with your latch on that is already installed on your post and mark the 2 hole locations. (Fig. 1 & 2)
6. Drill 2 pilot holes for the striker piece.
7. Mount the striker with 2 included #10x 1-1/4" pan head screws.
8. Test gate operation to make sure the striker and latch match up.

