



PUSHBAR-H: INSTALLATION INSTRUCTION


① Explosion & Dimensions



* FOR H-METAL lock only



② Left or right turning gate



③ Mounting

